FF600 RETRACTOR SERIES SYSTEMS

The FF600 Retractor System is a proven and convenient way to secure passengers in wheelchairs. Our dual, 24-teeth sprocket mechanism enables the user to more easily increase tension on the webbing. And the versatility of the system offers users a choice — S-hook or Buckle & Tab hardware attachment styles.



ACCESSORIES

AL701061

Series L Connector Assembly Kit

This kit converts AL700 Titan Series and FF600 Series wheelchair tie-down retractor assemblies to a Series L Track application.



AL701052 - 14

Series A Connector Assembly Kit

This kit converts AL700 Titan Series and FF600 Series wheelchair tie-down retractor assemblies to a Series A Track application.



Q8-7580SL

SNC Connector Assembly Kit

This kit converts AL700 TITAN Series and FF600 Series wheelchair tie-down retractor assemblies to a SNC Cleat fitting application.



STANDARDS COMPLIANCE

FF600 Retractor Series Systems when properly used with a complete Sure-Lok System, comprised of wheelchair tie-down, a complete occupant restraint system (including lap and shoulder belt), track and anchorages are designed to meet the following requirements where applicable:

- 30mph/20g Impact Test Criteria per SAE J2249
- 30mph/20g Impact Test Criteria per National Standards for School Buses
- 30mph/20g Impact Test Criteria per Canadian Z605 Standard
- 30mph/20g Impact Test Criteria per ISO 10542 Standard
- 49 CFR Part 38 Americans with Disabilities Act (ADA)
- 49 CFR Part 571.222 (FMVSS 222) School Bus Passenger Seating and Crash Protection
- FMVSS 302 Flammability Test
- Certificates of Conformance available upon request.





Always secure the occupant in the vehicle with a complete Sure-Lok Occupant Restraint System, consisting of lap and shoulder belts. Secure the wheelchair in the vehicle with a Sure-Lok Wheelchair Tie-Down System.

- Our track fittings are specifically designed to ensure free pivoting action for optimum belt alignment to the securement point on the wheelchair.
- 2. D-ring configuration provides an easy attachment point for the snap hook on an integrated occupant restraint system.
- 3. The ergonomically designed handle is quick and easy to grasp when applying tension to the retractor webbing. The chrome-plated metal cover provides a strong, durable finish.
- 4. The FF600 Series positive-locking retractor offers a choice for operators to tension the retractor to the desired load, locking the webbing at any length, including when fully retracted into the housing.
- 5. Retractor systems featuring Integrated Combination Belts are the most convenient securement system choice for operators.

FF600 RETRACTOR SERIES SYSTEMS

Determine which FF600 Retractor System is right for you. Select the Floor Anchor type you have or want installed, and choose the attachment style. Then just order the corresponding kit part number. It's that easy. Retractor assembly part numbers are listed in the chart below and retractor kit part numbers are in the charts on the opposite page. For more information on occupant restraints, refer to pages 20-25.





LTRACK	A TRACK	SNC	
FE200855S	FE200857S	FE200944S-SNC	RIGHT HAND RETRACTOR S-HOOK
FE200907S	FE200925S	FE200945S-SNC	LEFT HAND RETRACTOR S-HOOK
FE200855	FE200857	FE200944-SNC	RIGHT HAND RETRACTOR BUCKLE & TAB
FE200907	FE200925	FE200945-SNC	LEFT HAND RETRACTOR BUCKLE & TAB
4			



BUCKLE & TAB



SNC FLOOR ANCHOR Q8-7580-A

RETRACTOR KITS WITH OCCUPANT RESTRAINTS

FLOOR ANCHOR TYPE	ATTACHMENT STYLE	KIT PN	PN IN KIT	QTY	OCCUPANT RESTRAINT
LTRACK	s-hook	FF612S-4C	FE200855S FE200907S FE200727HA	2 2 1	•
0	BUCKLE & TAB	FF612S-4C	FE200855 FE200907 FE200727HA	2 2 1	
ATRACK	S-HOOK	FF615S-4C	FE200857S FE200925S FE200727HA	2 2 1	FE200727HA
	BUCKLE & TAB	FF615-4C	FE200857 FE200925 FE200727HA	2 2 1	
SNC	S-HOOK	FF660S-4C-SNC	FE200944S-SNC FE200945S-SNC FE200727HA Q8-7580-A	2 2 1 4	
	BUCKLE & TAB	FF660-4C-SNC	FE200944-SNC FE200945-SNC FE200727HA Q8-7580-A	2 2 1 4	

RETRACTOR KITS WITHOUT OCCUPANT RESTRAINTS

FLOOR ANCHOR TYPE	ATTACHMENT STYLE	KIT PN	PN IN KIT	QTY	OCCUPANT RESTRAINT
LTRACK	S-HOOK	FF627S-4C	FE200855S FE200907S	2 2	
0	BUCKLE & TAB	FF627-4C	FE200855 FE200907	2 2	5 1110
A TRACK	S-HOOK	FF628S-4C	FE200857S FE200925S	2 2	For available Occupant Restraints, refer to pages 20-25. WARNING Always secure the occupant in the vehicle with a complete Sure-Lok Occupant Restraint System, consisting of lap and shoulder belts. Secure the wheelchair in the vehicle with a Sure-Lok Wheelchair Tie-Down System.
	BUCKLE & TAB	FF628-4C	FE200857 FE200925	2 2	
SNC	S-HOOK	FF661S-4C-SNC	FE200944S-SNC FE200945S-SNC Q8-7580-A	2 2 4	
	BUCKLE & TAB	FF661-4C-SNC	FE200944-SNC FE200945-SNC Q8-7580-A	2 2 4	